

DEW POINT CALCULATION CHART (FAHRENHEIT)
AT 30 HG BAROMETRIC PRESSURE

		Ambient Air Temperature °F										
		20	30	40	50	60	70	80	90	100	110	120
% Relative Humidity	90	18	28	37	47	57	67	77	87	97	107	117
	85	17	26	36	45	55	65	75	84	95	104	113
	80	16	25	34	44	54	63	73	82	93	102	110
	75	15	24	33	42	52	62	71	80	91	100	108
	70	13	22	31	40	50	60	68	78	88	96	105
	65	12	20	29	38	47	57	66	76	85	93	103
	60	11	19	27	36	45	55	64	73	83	92	101
	55	9	17	25	34	43	53	61	70	80	89	98
	50	6	15	23	31	40	50	59	67	77	86	94
	45	4	13	21	29	37	47	56	64	73	82	91
	40	1	11	18	26	35	43	52	61	69	78	87
	35	-2	8	16	23	31	40	48	57	65	74	83
30	-6	4	13	20	28	36	44	52	61	69	77	

Dew Point: The temperature at which moisture will condense on the surface. No coatings should be applied unless the surface temperature is a minimum of 5°F above this point. Temperature must be maintained during curing.

Example: If air temperature is 70°F and relative humidity is 65%, the dew point is 57°F. No coating should be applied unless the surface temperature is 62°F minimum.